

EKVG | Vagar

Local operating procedures for EKVG.

- [LAI 1 - Vagar](#)

LAI 1 - Vagar

1. Vagar Airport (EKVG)

Vagar Airport is a hybrid of many sorts. Before controlling at EKVG you must:

- Hold an S3+ rating or be S2 with an endorsement
- Complete the material on Procedural Airport
- Be confident with AFIS operation
- Read and understand the EKVG part of the ATC training handbook of Iceland, to have clear understanding of Oceanic procedures

EKVG_I_TWR - 118.325
BIRD_E1_CTR - 126.750

Runways	Type of APP	Missed Approach	Type of Departure	Noise Abatement
12	LOC, NDB, RNP-AR	Refer to active charts. Many different ones, depending on active procedure	SID (RNP-AR) Or Visual Departure	NIL
30	ILS, LOC, RNP-AR			

1.1 ATC clearance & Ground operation

Airspace limits	Airspace class	Climb clearance	ACC Sector	Descend clearance
GND - FL75 (60 nm.)	G	7000'	BIRD_E_CTR	7000'

Vagar airport is AFIS meaning you must use AFIS phraseology and clearance structure, However at EKVVG controller may issue startup clearance, due to oceanic clearance being needed before startup can be commenced.

All ATC clearances must be obtained from Reykavik control, before start-up is issued. Issue should be obtained from BIRD_E_CTR, if online. If not, revert to BIRD_CTR or BICC_FSS

Airport is condensed and all departure and arrivals must backtrack the active runway, so keep concentrated and issue appropriate information.

For more information regarding Oceanic clearance: [Icelandic Wiki - Clearance](#)

1.2 Arrival Procedures

EKVVG AFIS (EKVVG_I_TWR) will provide Arrival Information including:

- Runway in use
- Local QNH
- Transition Level
- Turbulence expectation (See table below)
- Any other relevant information

EKVVG_I_TWR is a TIZ zone which extends from GND-7500'. Refer to [AFIS Procedures](#)

Aircrafts should be handed over from BIRD_E_CTR, if online. If not expect handover from BIRD_CTR or BICC_FSS. Aircrafts are cleared:

Runway 12			
Direction	Point	Altitude	Procedure
East	MY	7000'	Enter Base turn to descend 3700 to exec. LOC 12
South			
West			Enter holding to descend 3700 to exec.


North

Runway 30

Direction	Point	Altitude	Procedure
East	ROBUR	7000'	Straight in ILS Z Runway 30
South			
West	VG		Full procedure ILS Z Runway 30
North			

Note RNP-AR is covered in its own topic.

1.2.1 Turbulence chart




Live updated turbulence information can be found [here](#)

1.2.2 MSA

MSA is 4000' in 25 nm. radius

1.2.3 Approach procedures



- A319 & A320 & A32N with SAS

Other airlines may get these on request only, and should be limited to Airbus & Embraer aircraft, as others may not have these capabilities.

In case of RNP-AR following procedures are applicable.

Runway 12			
Direction	Point	Altitude	Procedure
East	ROBUR	7000'	Full procedure RNP V or RNP W
South	SUDUR		
West	MAGNI		
North			

Runway 30			
Direction	Point	Altitude	Procedure
East	ROBUR	7000'	Straight in ILS V, RNP W, RNP V or RNP U
South	SUDUR		RNP W, RNP V or RNP U
West	MAGNI		Full procedure ILS V, RNP W, RNP V or RNP U
North			

See charts for ILS V, RNP V, RNP U and RNP W layout.

1.3.2 NDB Visual approach

NDB visual approaches is available on pilot request only during daylight hours. This approach transitions to two available visual segments.

- Waterfall visual approach: Only for VFR & RNP-AR approved A/C (1.3.1)
- Standard visual segment: Available for everyone

1.4 Departure procedures

EKVG has established SIDs which are given as pr. BIRD instructions however appropriate SIDs should be assigned.

Directrion	Runway 12		Runway 30		Initial climb	
	Other A/C	SID (RNP-AR)	SID (RNP-AR)	Other A/C		
East	Visual Departure	ODEVA2P/2N	LUVEK2S/2T/2 W	Visual departure	7000'	
South		RAKUP2P/2N	RAKUP2S/2T/2 W			
West		MY2P/2N	MY2S/2T/2W			
North						

1.4.1 Visual Departure

All aircraft which does not live up to 1.3.1 RNP-AR requirements must perform a VFR departure, and hence visibility must be more than 3KM, and no clouds below 3000' AGL

If the pilot is aware of this, and wishes to bust the VFR minima, it is his discretion.

A visual departure is given by stating:

- After Departure climb visually, when clear of terrain, proceed direct to [Point]

1.4.2 SID-AR departures

For Airbus & other capable aircrafts, SID-AR are available.

Different ones are available, and must be used according to wind direction

Wind direction	SID name depending on direction of departure.	
	Runway 12	Runway 30
020 - 040	ODEVA/RAKUP/MY 2S departures	ODEVA/RAKUP/MY 2P
040 - 150		RWY not in use
150 - 200	ODEVA/RAKUP/MY 2T departures	
160 - 200	ODEVA/RAKUP/MY 2W departures	
200 - 230		ODEVA/RAKUP/MY 2N departures
230 - 260	RWY not in use	ODEVA/RAKUP/MY 2P departures
260 - 020		

After departure, when aircrafts are reporting airborne they should be transferred to the appropriate controller (BIRD_E_CTR, BIRD_CTR or BICC_FSS)