

BEFORE STARTING ENGINE

| | |
|------------------------|-----------|
| ALL NECESSARY SOFTWARE | OPENED |
| VATSIM | CONNECTED |
| FLIGHT PLAN | FILLED |
| POWER LEVER | IDLE |
| PARKING BRAKE | ON |
| STROBE LIGHT | SET |

AFTER STARTING ENGINE

| | |
|---------------|------------------|
| OIL PRESSURE | CHECKED |
| RPM | CHECKED |
| ALTIMETERS | SET FOR QNH ____ |
| NAV AIDS | SET |
| PARKING BRAKE | SET |
| T/O BRIEFING | COMPLETED |

BEFORE TAKEOFF

| | |
|---------------------|------------------|
| BRAKES AND STEERING | CHECKED |
| FLIGHT INSTRUMENTS | CHECKED |
| FLAPS | SET FOR ____ |
| TRIM | SET |
| TRANSPONDER | SET |
| VOTER SWITCH | CHECKED AND AUTO |
| ECU TEST | COMPLETED |
| FUEL PUMPS | ON |
| FUEL QUANTITY | CHECKED |
| ALTERNATE AIR | OPEN OR CLOSED |

CLIMB

| | |
|----------------|----------------------|
| FLAPS | UP |
| FUEL PUMPS | OFF |
| POWER | SET |
| ALTIMETERS | SET FOR QNH/STD ____ |
| ICE PROTECTION | SET |

APPROACH

| | |
|-------------------|--------------------------|
| APPROACH BRIEFING | COMPLETED |
| LANDING LIGHT | ON |
| ALTIMETERS | SET |
| ICE PROTECTION | PITOT ON / ALTERNATE A/R |
| FUEL PUMPS | ON |
| NAVS | SET |
| FUEL TRANSFER | COMPLETED |

BEFORE LANDING

| | |
|-------|-----------------|
| FLAPS | SET FOR LANDING |
|-------|-----------------|

INSTRUMENT CIRCUIT - CLIMB

| | |
|------------|----|
| FLAPS | UP |
| FUEL PUMPS | ON |

INSTRUMENT CIRCUIT - CLIMB

| | |
|-------------------|-----------|
| APPROACH BRIEFING | COMPLETED |
|-------------------|-----------|

PARKING

| | |
|---------------|-------------|
| FLAPS | UP |
| PITOT HEAT | OFF |
| ALTERNATE AIR | CLOSED |
| FUEL PUMPS | OFF |
| FUEL QUANTITY | CHECK |
| TRANSPONDER | SQUAWK 2000 |

ENGINE SHUT DOWN

| | |
|-------------|--------------|
| ELEC MASTER | OFF |
| ALL LIGHTS | OFF |
| VATSIM | DISCONNECTED |