

ENVA - Trondheim

Værnes

Overview

Welcome to Trondheim! Home of the most flown domestic city pair together with Oslo. Also the home of "Hell", great moustache styling and rock. But do not forget the airport. It is the 3rd busiest airport in Norway as it is a domestic hub for commuters to the smaller airports in Norway. Trondheim host also several flight towards nordic and European destinations.

Stands

<https://stands.vatsim-scandinavia.org/?icao=ENVAframeless=true>

Stands	Assigned to
23-29	Commuter Domestic
30-37	Domestic flights
40-44	International flights

Apron	Assigned to
M1	De-Ice Pad
M2	GA
M3	GA Ambulance flights
M4-M6	Military parking

IFR clearance

Initial contact is with Ground, reporting callsign, stand number, and latest ATIS identification letter and QNH

Push-back

Most of the terminal gates requires straight-back pushes, however a few have turn-pushes. If you are not sure how pushback is executed from your stand, please have a look on the pushback maps which will show how we want you to perform the pushback.

Pushback maps

Runway 09 in use



Runway 27 in use



*Click on image to expand it's size

ATC can deviate from standard procedures if it's more optimal for the current traffic situation. If it's the case you can expect pushback instructions once the pushback clearance is given.

Taxi

Taxi instructions normally contains the full taxi route, however the runway intersection is not always included. If for example “holding point runway XX” is stated in your instruction, you may call ATC with “CALLSIGN, ready via ” as you approach this intersection, and it may be approved if traffic permits. Make sure to double-check if you are able to use the runway length from the intersection before requesting it.

SIDs

All SIDs are individually numbered for each runway. When receiving your clearance, know that the SID stated is only valid for one runway, in case the controller forgets to state the departure runway. RNAV SIDs (including OMNI-departure) has an initial climb altitude of 6000 ft. If you are unable to follow the published SIDs (old AIRAC, default or non-database freeware aircraft, etc.), request an Omni-directional departure. It is important that you NEVER climb above the initial climb without ATC clearance, as STARs and SIDs cross each other at different altitudes.

W and X procedures have earlier turns, and thus is only available to slower flights with TAS below 300.

STARs

Trondheim Værnes is using a “Point Merge System”, or PMS for all arrivals. This means that all STARs end up in a “fan” made out of waypoints (study the STAR charts), in which pilots should always be prepared for a direct routing towards the merge waypoint, 4 in total, in order to ease the workload of approach ATC.

The last fix of the STAR (or Merge Point) is followed by a transition to the ILS approach for each runway. ATC often replace these with vectoring, but always be prepared to fly

the transition, and do NOT fly direct from the merge point to the Final Approach Fix. If you have no transitions available, inform ATC and request vectoring. Study the approach charts, and make sure to always follow altitude and speed restriction, unless otherwise instructed by ATC

??Recommended descend restrictions

All STARs to Trondheim are by standard giving a descend profile, based on flying along the STAR throughout. In almost all situations, a DCT to STAR merge point will be given. Therefore a set of recommended altitudes at given points is added to charts and text pages to guide and give an optimum descend profile to the approach. We highly recommend programming this in FMS/FMC in good time prior to your top of descend and pre-program your expected STAR

Runway 09

Designator	Recommended Altitude
MIVSO xL	Cross VA414 at 7000 ft
NELSU xL	Cross VA414 at 7000 ft
NUPGO xL	Cross TUDLU at 7000 ft
VEVOD xL	Cross NEDIV at 7000 ft

Runway 27

Designator	Recommended Altitude
MIVSO xL	Cross ADEXA at FL 90
NELSU xL	Cross ADEXA at FL 90
NUPGO xL	Cross ALENU at FL 90
VEVOD xL	Cross ADEXA at FL 90

Approach

The default approach to Værnes is ILS for all runways. RNAV or visual approaches are available on request.

Visual approach is usually flown via MALOV (Runway 09) and TUSMO (Runway 27).

Direct routings

In Norway, direct routings are often used. Both arriving and departing traffic should be prepared to fly direct the end of SIDs, STAR Merge Points, and airspace border fixes. Make sure you have your filed route and waypoint page available to quickly accommodate direct routings.

Communications

You can always check online positions and sectors by visiting vatglasses.uk

ENVA_ATIS - Værnes ATIS - 127.550

ENVA_GND - Værnes Ground - 121.600

ENVA_TWR - Værnes Tower - 119.400

ENVA_APP - Værnes Approach - 118.600

ENVA_D_APP - Værnes Director - 119.150

ENBD_CTR - Polaris Control (Bodø ACC) - 126.450

ENBD_S_CTR - Polaris Control (Oslo ACC south) - 125.700

ENBD_C_CTR - Polaris Control (Bodø ACC central split) - 118.550

ENOR_SC_CTR - Polaris Control (Bandbox South Central/ENSV+ENOS+ENBD_S) - 134.515

ENOR_CTR - Polaris Control (Bandbox) - 125.500

ENRC_N_CTR - Værnes Tower (Bodø Remote Tower Center) - 118.325

Revision #19

Created 28 April 2023 17:53:37 by Daniel Lange (1352906)

Updated 17 December 2024 11:13:05 by Marius Linge (1621930)