

BORNHOLM

RØNNE

BORNHOLM HEMS

FAU

ROENNE-ROE
112.000 / CH 57X
ELEV 79

BORNHOLM RØNNE
52 L H 20.02
118.330

CTR D1500

SWEDEN FIR

1000 GND

08

ERTHOLMENE
Christiansø
FI (1) W 5 sec

DUEODDE
Dueodde
FI (3) W 10 sec

AMROR

KOLOB

GOSOT

POKEN

DETNI

KEKOV

GIROR

NEXØ

BALK

SNØGEBÆK

ØSTERMARIE

ØSTERLARS

LISTED

SVANEKE

ÅRSDALE

LOBBÆK

NYLARS

VESTERMARIE

NYKER

MULEBY

HASLE

TEJN

GUDHJEM

SANDVIG

HAMMER ODDE
FI (2) W 15 sec

Hammer Odde

435

374

1415

965

640

401

415

540

372

151

10500' MSL

23000' MSL

EK R 96

EK R 95

334

81

27

170

175

75

08

07

06

05

04

03

02

01

00

09

10

11

12

13

14

15

16

17

18

19

20

21

22

23

24

25

26

27

28

29

30

31

32

33

34

35

36

37

38

39

40

41

42

43

44

45

46

47

48

49

50

51

52

53

54

55

56

57

58

59

60

61

62

63

64

65

66

67

68

69

70

71

72

73

74

75

76

77

78

79

80

81

82

83

84

85

86

87

88

89

90

91

92

93

94

95

96

97

98

99

100

101

102

103

104

105

106

107

108

109

110

111

112

113

114

115

116

117

118

119

120

121

122

123

124

125

126

127

128

129

130

131

132

133

134

135

136

137

138

139

140

141

142

143

144

145

146

147

148

149

150

151

152

153

154

155

156

157

158

159

160

161

162

163

164

165

166

167

168

169

170

171

172

173

174

175

176

177

178

179

180

181

182

183

184

185

186

187

188

189

190

191

192

193

194

195

196

197

198

199

200

201

202

203

204

205

206

207

208

209

210

211

212

213

214

215

216

217

218

219

220

221

222

223

224

225

226

227

228

229

230

231

232

233

234

235

236

237

238

239

240

241

242

243

Rønne/Bornholms Lufthavn is the only procedural tower in Denmark.

The airport is serving around 200.000 passengers yearly on its routes. The primary operator DAT, serves the weekly/daily routes to EKCH, EKYT & EKBI.

Procedural Tower

As Rønne is a Procedural tower, means that they serve as an "normal" controlled airport, however without their own radar. They therefore rely solely on aircraft information and data from the Swedish radars.

As they do not have their own radar, there is not any APP. The entire airspace is covered by the TWR. All arrivals and departures therefore have to either follow standard arrival or visual. No radar vector can be provided

Airspace

The entire airspace is Class D. First sector from GND-1500' and second from 1500 - 3500 ft.


Procedures

Remember EKRN does NOT have an ATIS, hence all A/C must be offered the latest MET-Report, including RWY in use and TL for inbounds!

Inbounds

All inbounds are handed over from Sweden at 5000 ft. (On ESMM QNH) DCT ROE VOR (Or otherwise coordinated)

TWR may request any aircraft DCT to any WP on the arrival. ODMEI, FAU & ULRED is some of the best/most used.



When an aircraft is inbound FAU, they will after the WP turn "downwind/base". Be noted the turning curve is different based of aircraft type. After the "Teardrop turn" they will establish on ILS.

To avoid the teardrop from an annoying angle, they may be cleared DCT ULRED for a straight in ILS

Proc.	West	North	East	South
ILS/LOC/VOR Runway 11	Intercept ROE Radial 291 inbound to intercept [ILS]	Direct ROE for base turn procedure.		
RNP Runway 11	Direct ODMEI	Direct OGTET		Direct LUKAG
ILS/LOC/VOR Runway 29	Direct FAU for base turn procedure		Direct ULRED for final runway 29	
RNP Runway 29	Direct GOTOG	Direct ASBAX	Direct ULRED	Direct GOTOG

Departures

All IFR departures must be coordinated with Sweden, and they must be the ones approving and issuing the Clearance.

Initial climb is always Maximum 3000 ft. and handed directly over to ESMM_APP

All departures are Omnidirectional.

RWY 11 - Climb straight to 700 ft. then turn

RWY 29 - Climb on track 274 to 700/1000 ft. then turn

Phraseology

Exactly the same as a normal TWR.

Only to remember an aircraft can NOT be identified.

For clearance, remember to include: "*Sweden clears you...*"

For a teardrop approach, following is used: "***C/S, via FAU cleared full ILS-Z approach RWY29. Report FAU outbound***"

For a straight in approach: "***C/S, via ULRED cleared straight in approach ILS-Z. Report final***"

A flight into EKRN might sound like this:

- Rønne TWR hello, DNU46R passing FL060 for 5000 ft. inbound FAU NDB
- DNU46R, Rønne TWR hello. RWY 29 in use. TL040, Rønne QNH 1013. Expect ILS-Z approach RWY29 via FAU. Do you require the latest METAR?
- TL040, QNH 1013, expecting ILS-Z RWY29 via FAU. Negative we have the latest weather onboard. DNU46R
- DNU46R, roger. Descend 2000 ft. via FAU cleared full ILS-Z approach RWY29. Report Final
- Descend 2000 ft. via FAU cleared full ILS-Z approach RWY29. We will report Final. DNU46R
- Establish on final RWY29, DNU46R
- DNU46R, roger, winds 300/14 RWY29 cleared to land
- Cleared to land RWY29, DNU46R

A flight out of EKRN might sound like this:

- Rønne TWR hello, DNU49K, stand 1 request IFR clearance to EKYT
- DNU49K Rønne TWR hello. Request on standby, expect clearance during Taxi. RWY11 in use. Do you require the latest MET-Report?

- Roger clearance during taxi, RWY11 in use, negative we have the latest weather onboard. DNU49K
- DNU49K, roger. Rønne QNH 1013, startup approved, report ready for taxi.
- Startup approved, QNH 1013 report ready for taxi. DNU49K
- TWR, DNU49K ready for taxi.
- DNU49K, Roger, taxi H/P RWY11 via A. Report ready to copy IFR clearance.
- Roger taxi H/P RWY11 via A, we are ready to Copy, DNU49K
- DNU49K, Sweden clears you to EKYT via Flight planned route. Initial climb 3000 ft. SQ1234. After departure RWY11, follow standard noise abatement procedure.
- Cleared to EKYT via Flight planned route. Initial climb 3000 ft. SQ1234. After departure RWY11, follow standard noise abatement procedure, DNU49K
- DNU49K read back correct, report ready for departure
- Ready for departure, DNU49K
- DNU49K roger, winds 150/21 RWY11 cleared for takeoff. Report turning
- Cleared Takeoff RWY11, report turning DNU49K
- TWR, DNU49K turning right.
- DNU49K, Roger. Contact Sweden on 136.135, bye!
- Sweden on 136.135 DNU49K, adios!

Coordination

All departures must be coordinated and approved, however Flights to EKCH may be cleared via TIDVU without coordination

See LOA with Sweden for more info

Revision #5

Created 26 April 2024 13:39:39 by Jeppe Seier (1602589)

Updated 13 December 2024 03:32:28 by Jeppe Seier (1602589)